



## **PB206 Panic Button**

---

Quick Start Guide

# **1** Introduction




The PB206 ZigBee Panic Button is used to send panic alarm to the mobile app by simply pressing the button on the controller.

This guide will provide you with an overview of the product and help you get through the initial setup.


## 2

## Get to know your device




### 1. Panic button

- **Send Alarm.** Press to send the panic alarm to the mobile app.



## **6. Battery compartment**

Insert battery here to power on the panic button.



## **7. Lock button**

You can lock/unlock the panic button by switching the side lock (you cannot use the panic button when it is locked).

## **8. Reset button**

Press and hold the reset button for ten seconds until the LED indicator flash green once to restore the panic button to default factory setting.

## 3

## Get started

### 3.1 To get started, you will need:

A SEG-X3 Smart Gateway

The SmartOWON mobile app.

### 3.2 Connect to gateway's network

1. Set your gateway to permit joining.
2. Power on the panic button. Press the reset button once and the LED indicator will flash red for three times indicating the panic button is ready to join the gateway's network.
3. The panic button will join the gateway's network automatically. The LED indicator will flash green for three times when it has successfully joined.
4. Now you can use the panic button in your system.

## 4

# Technical Specifications

<b>Battery</b>	<ul style="list-style-type: none"><li>• CR2450V 850Mah Lithium battery</li></ul>
<b>Working Temperature</b>	<ul style="list-style-type: none"><li>• -10°C~+45°C</li></ul>
<b>Humidity</b>	<ul style="list-style-type: none"><li>• &lt;=85%RH</li></ul>
<b>Networking Mode</b>	<ul style="list-style-type: none"><li>• ZigBee 2.4GHz IEEE 802.15.4</li></ul>
<b>Networking Distance</b>	<ul style="list-style-type: none"><li>• Outdoor/Indoor range: (100m/30m)</li></ul>
<b>Operating Ambient</b>	<ul style="list-style-type: none"><li>• Temperature: -10~45°C</li><li>• Humidity: up to 85% non-condensing</li></ul>
<b>Dimensions</b>	<ul style="list-style-type: none"><li>• 37.6(W) x 75.66(L) x 14.48(H) mm</li></ul>
<b>Weight</b>	<ul style="list-style-type: none"><li>• 31 g</li></ul>

## 5 Safety Notice

**WARNING:** Failure to follow these safety notices could result in fire, electric shock, other injuries, or damage to the panic button and other property. Read all the safety notices below before using the panic button.

- Avoid high humidity or extreme temperatures.
- Avoid long exposure to direct sunlight or strong ultraviolet light.
- Do not drop or expose the unit to intense vibration.
- Do not disassemble or try to repair the unit yourself.
- Do not expose the unit or its accessories to flammable liquids, gases or other explosives.